


## British Autogard Ltd

2 Wilkinson Road, Love Lane Industrial Estate, Cirencester, GL7 1YT, UK  
Tel: +44-1285 640333 Fax: +44-1285 659476

### Installation and maintenance manual

#### 200 series torque limiter

The information in this manual is the property of British Autogard Limited. It may only be reproduced with our express permission.



#### PRINCIPLES OF OPERATION

Autogard torque limiters use the principle of torque transmission through hardened steel balls positioned in conical ball seats in opposing faces of hardened steel plates.

The ball seats in the drive plate (3) and the slide plate (4) hold the steel balls (21) in position. On disengagement the balls are retained in their pitch circle by the cage plate (5).

The tendency of a torque load to cause the balls to ride out of their seatings, forcing the plates apart is opposed by an adjustable spring load. Adjustment of this spring load, and therefore of tripping torque, is achieved by means of the adjusting nut (6).

#### TORQUE ADJUSTMENT

In cases where the limiting torque is specified, units are preset at the factory and steel sleeves (11), known as calibration spacers, are fitted to prevent the adjusting nut (6) from being accidentally overtightened. However, it is sometimes difficult to determine accurately the precise level at which torque should be controlled. In such circumstances it is recommended that the drive is started up with the torque limiter at a low setting, and the adjusting nut (6) progressively tightened until the unit will enable the drive to start and run without tripping.

**Note!** The adjusting nut (6) is locked in position by a socket set screw (24) which must be released before any change of setting and relocked after adjustment.

**CAUTION:** *It is important that the spring (22) is not over-tightened. If it is not free to deflect sufficiently to permit full tripping movement of the slide plate (4), the Autogard will be prevented from tripping. Table 2 gives the spring ratings and minimum operating lengths.*

### RE-ENGAGEMENT AFTER TRIPPING (AC & ACT TYPES)

Types AC & ACT are automatic reset units and all that is required to re-engage the Autogard is to rotate the drive until the balls (21) roll into the next seat. The ACT units have staggered seatings on two or more pitch circles which provide a synchronous (timed) reset, always resetting in the same position.

**CAUTION:** *It is necessary to shut down the drive quickly after disengagement. Therefore, in all applications using the AC / ACT type Autogards it is recommended that a limit switch is fitted to sound an alarm and / or switch off the drive. The switch can be activated by the limit switch operating plate (12) supplied with each unit.*

### RE-ENGAGEMENT AFTER TRIPPING (AF TYPE)

Type AF (manual re-engaging) units are fitted with a star shaped cam plate (7) screwed to the drive plate (3) and an engaging plate (5) instead of the cage plate. On overload, the cam plate (7) forces the balls (21) radially outwards along the slots in the engaging plate (5). This ensures the drive balls run freely on a track outside the ball seatings and so prevent the unit resetting.

To return them to the drive position, rotate either side of the unit until the slots in the periphery of the engaging plate (5) line up with slots in the drive plate (3). Lock the two plates in this position with any convenient tool (eg screwdriver or hexagonal key), and rotate them relative to the slide plate (4). If the correct direction of rotation is chosen, the balls will track inwards to engage with their seatings in the drive plate (3) after about 30 degrees of rotation. Further rotation may be necessary subsequently to engage the slide plate seats.

**Note!** The Autogard will trip in either direction, but the direction of rotation for re-engaging is controlled by the engaging plate (5) and may be changed if necessary by turning this plate over.

### TORQUE LIMITER / DRIVE MEDIUM DETAILS

**MODEL 221** This unit incorporates bearings onto which the drive medium is mounted. The adaptor plate (10) is supplied with threaded and plain holes to allow fixing of the drive medium using screws and dowels. The drive medium must be bored to dimension M (see Table 1). The bearings may then be pressed into the bore. After pressing, the final bore of the bearing must be to dimension G. For sizes 1-3 a fitting pin is recommended, to ensure the correct bore size after pressing. The drive medium with its bearing can then be fixed to the adaptor (10), using screws and dowels. The positions of the standard fixing holes are given in Table 1.

Size	Bearing data mm		Mounting data		mm
	Ø M (H7)	Ø G (H7)	PCD	Screws	Dowels
1	25.4	22.225	36	3 x M4	3 x Ø4
2	44.45	38.100	58	3 x M5	3 x Ø5
3	57.175	50.800	70	3 x M6	3 x Ø6
4	77.790	71.476	95	3 x M8	3 x Ø8
5	114.300	101.727	135	3 x M10	3 x Ø10
5S	171.400	152.400	*	*	*

Table 1 :- Drive media fixing data for model 221

**MODEL 201** This unit incorporates an adaptor (10) to facilitate the fitting of a sprocket etc, using a taper bush or screws / dowels. If screws / dowels are used, a check should be made that sufficient screws / dowels are employed to transmit the required torque.

**MODEL 203** This unit may be mounted to the face of a flywheel or gear by means of screws / dowels. A check should be made that sufficient screws / dowels are employed to transmit the required torque.

**Note!** The drive medium must be mounted on its **own** bearings.

**MODEL 205** This model includes an Autoflex coupling which can accommodate 0.5° of angular misalignment. After fitting the Autoflex hub (2) and the torque limiter onto the shafts, the gap between the face of the Autoflex hub (2) and the adaptor (10) should be checked at several positions around the periphery. The *maximum allowable variation* in the gap (dimension “a” in Table 2) corresponds to 0.5° of angular misalignment.

Size	Max variation in gap (a) mm
1	0.23
2	0.35
3	0.46
4	0.58
5	0.89
5S	1.02

Table 2 :- maximum allowable variation in gap between coupling halves (model 205)

When assembling the flexring assembly (29) to the adaptor (10) and to the Autoflex hub (2), ensure that the bolts are tightened to the following torques :

<b>Size</b>	1/EB8	2/EB35 & 3/EB70	3/EB150 & 4/EB150	5/EB500 & 5S/EB800
<b>Torque Kg/M</b>	1.22	2.44	4.45	21.8

**MODEL 206** This model is fitted with a soft flexible coupling (10 & 2) to accommodate parallel and angular misalignment.

**Note!** It is recommended that “Loctite 242” or equivalent is applied to all screws.

## TORQUE SETTING

The setting as supplied will be within +/- 5% of the torque value specified on the order. If the factory adjustment has been altered during installation, make sure the adjusting nut (6) is returned to its original position. It is a good precaution to take a measurement from the end of the central hub (1) to the face of the adjusting nut (6) for future reference.

Starting torque is usually the highest torque that the unit must transmit and the level will depend on the inertia of the machine and the position of the Autogard within the drive. However, occasionally the torque limiter must be set to accommodate higher peak operating torques.

If an increased torque setting is desired, the length of the spring (22) must be reduced, by rotating the adjusting nut (6) clockwise (viewed from the “spring” end of the torque limiter). Ensure that the locking screw (24) is loosened before rotating the adjusting nut (6). See **torque adjustment**.

If the spring (22) is already at its minimum length (i.e. the torque limiter is at the high end of its torque range), it will be necessary either to replace it with a stiffer spring or to fit a larger torque limiter. See Table 2.

It may be possible to tighten the adjusting nut (6) without removing any calibration spacers (11). However, in most cases it will be necessary to remove one or more of the spacers (11).

**CAUTION: Care must be taken not to overtighten the spring (22). Please refer to the minimum operating spring lengths from Table 2.**

Size	Approximate torque range Nm		Spring				Minimum length mm
	AC and AF	ACT	Type	Code	Colour	Qty	
1	0.6 (1.0) - 6.8	0.9 (2.5) - 11.5	coil	1C3	white + yellow	1	18
	3.0 (4.5) - 14.5	1.8 (6.5) - 21.0	coil	1C2	white + green	1	21
	4.5 (9.0) - 28.0	3.5 (10.0) - 37.5	coil	1C1	white + red	1	23
	8.0 (8.0) - 43.0	13.0 (13.0) - 66.0	disc	1D1S	natural	6	13
2	4 (6) - 19	5 (9) - 25	coil	2C3	blue + yellow	1	19
	8 (20) - 60	15 (40) - 90	coil	2C2	blue + green	1	21
	15 (54) - 88	25 (100) - 130	coil	2C1	blue + red	1	26
	70 (70) - 200	100 (100) - 320	disc	2D2S	blue	5	23
	65 (130) - 225	95 (200) - 380	disc	2D1S	blue	6	24
3	6 (6) - 55	9 (9) - 80	coil	3C3	brown + yellow	1	25
	13 (15) - 135	18 (23) - 130	coil	3C2	brown + green	1	31
	28 (40) - 280	44 (60) - 400	coil	3C1	brown + red	1	37
	70 (70) - 400	95 (100) - 540	disc	3D1S	brown + black	6	24
	140 (140) - 700	155 (160) - 850	disc	3D1D	brown + black	8	30
4	40 (90) - 320	50 (110) - 400	coil	4C1	orange + red	1	50
	150 - 850	170 - 1000	disc	4D2S	orange	6	33
	230 - 1100	270 - 1700	disc	4D1S	orange + black	5	32
5	150 - 350	160 - 530	coil	5C1	grey + red	1	50
	230 - 2200	270 - 2650	disc	5D2S	grey	6	43
	500 - 2500	540 - 2900	disc	5D1S	grey + black	6	57
5S	940 - 5600	1150 - 6400	disc	5SD1	natural	5	48
	1400 - 7600	1600 - 8500	disc	Hi-torq	natural	5	53

Table 2 :- Torque ranges and minimum spring lengths

**Note : Minimum torque:** If a locking collar (15) is used (e.g. model 206), the **minimum** torque may increase. This alternative minimum is shown in brackets ( ).

Graphs giving torque curves against spring lengths are available from the factory but they are only approximate, owing to the tolerances inherent in spring manufacture.

## INITIAL START-UP

Prior to start up, examine the torque limiter to make sure it is correctly engaged with the balls (21) fully seated in both plates (3 & 4).

## MAINTENANCE

Journal bearings (18) are of either oil impregnated bronze or high grade, self lubricating PTFE tapes. These may be supplied loose with the torque limiter and care must be taken in installation to ensure that they are fitted. These bearings need no maintenance.

Needle bearings (19) are used to take the thrust loads. These bearings (19) and the driving balls (21) are greased during assembly at the factory, and after installation Autogard torque limiters can run for a considerable time without attention. Safe length of time without re-greasing is dependent upon frequency of operation and upon operating conditions, and may well be measurable in years in non-arduous applications. Our technical staff will be pleased to help with advice on applications in adverse conditions.

Model 205 - The steel flexrings should be checked during a normal service of the machine. If any are cracked or broken, the complete flexring assembly (29) should be replaced.

Model 206 - The rubber inserts should be checked during a normal service of the machine. If any are severely worn, broken or missing, a new complete set of inserts should be fitted.

## **SAFETY**

*As an Autogard Torque Limiter is normally installed as a rotating mechanism, it must be properly guarded in accordance with current Codes of Practice. Also, consideration must be given to the particular safety aspects of each application, such as the control of lifting equipment and the special hazards of explosive atmospheres.*

## **Addresses of spare parts stockists and service facilities**

British Autogard Ltd  
2 Wilkinson Road, Cirencester  
Glos, GL7 1YT  
England

Tel: +44 (0)1285 640333  
Fax: +44 (0) 1285 659476  
Email: [sales.uk@autogard.com](mailto:sales.uk@autogard.com)

American Autogard Corporation  
5173 26<sup>th</sup> Avenue  
Rockford, IL 61109  
U.S.A.

Tel: +1 815 633 1441  
Fax: +1 815 633 8488  
Email: [sales.us@autogard.com](mailto:sales.us@autogard.com)

---

Autogard Kupplungen GmbH  
Im Wied 2, D-32683  
Barntrup  
Germany

Tel: +49 (0)5263 9549 60  
Fax: +49 (0)5263 9549 69  
Email: [sales.de@autogard.com](mailto:sales.de@autogard.com)

Autogard Italia S.r.l  
Via Udine 3,  
20063 Cernusco sul Naviglio, Milano  
Italy

Tel: +39 (0)291 700471  
Fax: +39 (0)291 700472  
Email: [sales.it@autogard.com](mailto:sales.it@autogard.com)

---

Autogard Asia-Pacific Pty Ltd  
Unit 17, 56 Keys Road  
Cheltenham, Victoria 3192  
Australia

Tel: +61 (0) 39532 0901  
Fax: +61 (0) 39532 1032  
Email: [sales.au@autogard.com](mailto:sales.au@autogard.com)

Autogard Japan Ltd  
15-16, 2- Chome, Takanawa  
Minato-Ku, Tokyo 108  
Japan

Tel: +81 3 34499621  
Fax: +81 3 54497491  
Email: [sales.jp@autogard.com](mailto:sales.jp@autogard.com)